



2280 Avocado Avenue, Unit 4  
Melbourne, FL 32935, U.S.A.  
800-582-7508

## **Classic Clear Water Based Urethane Large Area (Floor) Application**

The application of Bristol Finish Classic Clear Water Based Urethane requires the same basic preparation steps as any conventional coating product. The old saying is completely true - proper preparation and application accounts for 90% of the final appearance and performance.

For helpful articles and expert advice on preparation, refinishing techniques, and much more view our website [www.bristolfinish.com](http://www.bristolfinish.com).

See the Material Safety Data Sheet on our website at [www.bristolfinish.com](http://www.bristolfinish.com) for safety, spill control, and waste disposal information.

### **Steps for Application**

Step One: Consult the product label for preparation requirements.

Step Two: Select a floor coating applicator known as a T-bar applicator. Be sure to shake or pull any loose fibers from T-bar applicator.

Step 3: Gently mix Classic Clear Water Based Urethane. Fill a plastic watering can with product. It is a good idea to fill near your starting point so any spills can be feathered into the floor.  
NOTE: If using Interior Soft Satin finish, please keep the working batch thoroughly mixed by shaking frequently.

Step 4: Pour a small puddle of finish on the floor to saturate the pad.

Step 5: Pour a 3' to 4' wide strip down the length of the floor to the opposite corner while pulling your applicator through the finish. Continue back and forth down the floor, pouring additional beads of finish as needed.

Step 6: Now overlap 4 to 6 inches. At this point, finish can be poured onto the floor from behind the applicator during each full-length pass. Be sure to angle the applicator (about 10 degrees) so finish runs off to the unfinished side of the floor. Do not allow a puddle of finish to form in front of the applicator.

Step 7: Move at a slow walk and be sure to pour down less finish as you approach the wall.

Step 8: Use caution on turns to eliminate puddles and missed areas.

Step 9: When watering can is empty, move it to an unfinished area to refill.

Step 10: After the first coat is applied, consult the product label for re-coat times. Wrap your applicator in a plastic bag.

Step 11: When the final coat of product is completely applied, discard any remaining finish from the watering can.

Step 12: Wash applicator head thoroughly with soap and water. Rinse and hang it to dry.

**NOTE**: Allow 24 hours of cure time after the last coat has been applied before opening area to traffic.